

LABOR-**SAVING** FEATURES

Standard installed weld nuts under driver-side floor for optional Ricon or B&D transfer seat base;
Labor Savings: 2 hours

Standard relocated low-profile muffler to increase ground clearance;
Labor Savings: 4 hours

Standard modified cross-member ready for optional bolt-in 2-piece driveline;
Labor Savings: 4 hours

Standard installed weld nuts for installation of Braun UVL or Vangator II wheelchair lifts;
Labor Savings: 4 hours

Standard removable heat shields to ease in adaptive equipment installations.
Labor Savings: 2 hours



Nor-Cal VANS

**1300 Nord Ave.
Chico, CA 95926
866-892-0150
fax: 530-892-0259**

