

LABOR-**SAVING** FEATURES

Standard installed weld nuts under driver-side floor for optional Ricon or B&D transfer seat base;

Labor Savings: 2 hours

Standard relocated low-profile muffler to increase ground clearance and accommodate Braun UVL wheelchair lift installations;

Labor Savings: 8 hours

Standard modified cross-member ready for optional bolt-in 2-piece driveline for Braun UVL installations;

Labor Savings: 8 hours

Standard installed weld nuts for installation of Braun UVL or Vangater II wheelchair lifts;

Labor Savings: 4 hours



Standard removable heat shields to ease in the installations of front driver or passenger position power wheelchair lock downs.

Labor Savings: 2 hours

Nor-Cal VANS

